

CONSUL WIRING DIAGRAM (AFTER OCTOBER, 1953)

On cars fitted with a water temperature gauge in place of an ammeter, the battery feed wire is taken direct to the *A* terminal of the regulator. A wire runs from this terminal to the ignition switch